



Polariscope

Fullauto StrainEye

LSM-9002

product family


Measures residual stresses by observing strain in glass or plastics.

Manufactured with high-quality optical filters.

Supporting customer measurements with more sophisticated software.









LSM-9002S [Equipped with a 6X zoom lens]

New Software


Equipped with new user-friendly software compatible with Windows11.(improvement of product life cycle)

Measurement Case Optical lens





1D Graph above shows retardation data along the line you set.




Graph above shows a histogram with the area you set in left result.


New Analysis Mode

Added defect detection mode, which is possible to be confirmed scratches, dents and foreign objects because local changes can be extracted and local distortion

[Standard Mode (Retardation)]



New Defect Detection Mode



Retardation standard

It can be used to calibrate polariscope. It is also possible to combine the desired phase difference by special order. Please contact us for details.



| Specifications Specifications Specifications Specifications Specifications Specifications Specification Specificat | | |
|--|-------------------|---------------------------|
| Model name | LSM-9002LE | LSM-9002S |
| Size(body) | W300×D353×H540 mm | W300×D353×H580 mm |
| Sample placement space (height) | 0~160 mm | 0~115 mm |
| Measurement area size | 205 × 205mm | MAX: 60×60mm MIN: 10×10mm |
| Measurementrange | Re : 0∼130nm | |
| Repeat accuracy | σ = 1nm | |
| Effective pixels | 1100×1100 | |



30-9 Ohyamakanai-cho, Itabashi-ku, Tokyo, 173-0024 TEL +81-3-3956-4111 FAX +81-3-3956-2335 URL https://luceo.co.jp/en/